
Subject: turntable problems

Posted by [depperdude](#) on Mon, 16 May 2005 22:26:22 GMT

[View Forum Message](#) <> [Reply to Message](#)

i just bought a sony PS-X45 turntable from a friend of a friend and when i hook it up, even if i turn the volume up very high, i can barely hear it over the speakers. any clues?depper

Subject: Re: turntable problems

Posted by [Manualblock](#) on Mon, 16 May 2005 23:46:43 GMT

[View Forum Message](#) <> [Reply to Message](#)

I tell you what. Post a picture of your table and your phone number and I'll help you.

Subject: Re: turntable problems

Posted by [colinhester](#) on Tue, 17 May 2005 00:19:34 GMT

[View Forum Message](#) <> [Reply to Message](#)

Are you plugging the turn table into a phono input or an aux input? If the later, then you will need to get a phono preamp.....Colin

Subject: Re: turntable problems

Posted by [Manualblock](#) on Tue, 17 May 2005 00:34:42 GMT

[View Forum Message](#) <> [Reply to Message](#)

This joker don't even have a turntable; or a life.
