
Subject: Re: Lenco Turntable
Posted by [Draco](#) on Sun, 29 Aug 2004 09:24:10 GMT
[View Forum Message](#) <> [Reply to Message](#)

Did you connect to a phono stage input? Are you connecting MM or MC? You must know be sure these things are done so check them to be sure.

Subject: Re: Lenco Turntable
Posted by [José](#) on Sun, 29 Aug 2004 17:24:23 GMT
[View Forum Message](#) <> [Reply to Message](#)

Many thanks. Yes I connect to a phono stage input in my amplifier (the same input I used with the other turntable- now out of service). The plugs are RCA. My trouble is I cannot get the phonocartidge's alignment properly, as the headshell included in the Lenco brings a cartridge and needle G 800E and I'm trying to use a Shure. Do you know if it is necessary to change the headshell. Please, what do you mean with MM or MC? Many thanks from Spain José.

Subject: Re: Lenco Turntable
Posted by [Draco](#) on Mon, 30 Aug 2004 08:30:02 GMT
[View Forum Message](#) <> [Reply to Message](#)

MM is moving magnet and MC is moving coil. MM is more common and if you hook up a MC cartridge to a MM input it will sound funny, like you said. Some have a switch to set which one you want.
