

---

Subject: Speaker replacement and problem with Laney VC30

Posted by [Anonymous](#) on Thu, 14 Jul 2005 09:40:27 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi everybody, I've recently bought a used Laney VC30 112. I've just bought an Eminence Legend GB12 to replace the old stock speaker. Now putting it in the speaker gives a fuzzy noise on certain notes played, mainly Cs (especially played on A-string). Can anyone help, please?!

---

---

Subject: Don't bother with answering, seems I have found the problem

Posted by [Anonymous](#) on Thu, 14 Jul 2005 09:57:26 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

---

Subject: Re: Don't bother with answering, seems I have found the problem

Posted by [Wayne Parham](#) on Thu, 14 Jul 2005 12:03:33 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

What was the problem? Was it not tightened down onto the baffle? Was something vibrating?

---

---

Subject: Re: Don't bother with answering, seems I have found the problem

Posted by [Anonymous](#) on Thu, 14 Jul 2005 15:04:04 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Two things: speaker has great depth, was too close to power tubes. Made them vibrate. And one had a broken solder joint, which was therefore constantly moving. Fixed the soldering and removed the card board stuff from the speaker frame so that I gained some space between speaker and tubes. Thanx for reply!

---

---

Subject: Re: Don't bother with answering, seems I have found the problem

Posted by [Wayne Parham](#) on Thu, 14 Jul 2005 16:53:31 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Gotcha, that makes sense. Glad you found it and thanks for letting us know.

---