
Subject: Mesa Boogie Single Rectifier Problem
Posted by [Nunzio](#) on Mon, 15 Aug 2005 15:32:09 GMT
[View Forum Message](#) <> [Reply to Message](#)

Sometimes when I play in Clean channel (channel 1) the amp cuts out and i have to give the amp a little smack for it to start working again. It only happens in channel 1. I have just replaced the power tubes and this problem still occurs.... could it be the preamp tubes or a short somewhere?

Subject: Re: Mesa Boogie Single Rectifier Problem
Posted by [Wayne Parham](#) on Mon, 15 Aug 2005 17:09:14 GMT
[View Forum Message](#) <> [Reply to Message](#)

You might look for dirty tube sockets and cold solder joints. Use some electronics cleaner on the tube sockets and inspect the solder joints looking for a dull surface, pitting or cracks.
