

---

Subject: Impedance selector switch??????

Posted by [Splatter1](#) on Thu, 12 Jan 2006 22:13:43 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Does anyone know where I can get an impedance selector switch for a 4X12 cabinet? I need to be able to switch the cab between 4 and 16 ohms. I have 4-4X12 cabs that I use for my stage setup that are all wired to 16 ohms. I have them hooked up so my amp see's a 4-ohm load. I have two more 4X12 cabs that are wired at 4-ohms that I bring in when I don't have the room for the other 4 on stage. I am running two heads with a headbone amp switcher, a Boogie mark IV and a Boogie mark III. When I am using just the two cabs, I run the top cab switched and the bottom cab straight into the mark III. The Boogies have 2-4ohm speaker outs. I would like to wire in an impedance selector on two of my main 4 cabs so I can change them to 4ohms when I don't have enough room to run them all. I have seen s cabs with a selector on them but cannot find them for sale. Any help would be appreciated.Thanks!!!!!!

---

Subject: Re: Impedance selector switch??????

Posted by [Damir](#) on Fri, 13 Jan 2006 12:19:51 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

That's how I'd do it - you need just the standard DPDT switch.Four ohms connection shown.

---

Subject: Re: Impedance selector switch??????

Posted by [Splatter1](#) on Fri, 13 Jan 2006 15:40:27 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Thanks, I didn't look at it that way.