
Subject: Does anyone know how to get a channel selector switch, to switch between two seperate amp's channels

Posted by [Robert](#) on Sat, 08 Dec 2007 20:21:08 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hello! I have a Mesa Boogie double recto and a Fender Deville and I have them both going through a ABY switch to be able to play them both at the same time with one guitar. My problem is, I can't really switch the channels both at the same time to clean or distortion. Does anyone know how I could maybe connect them together to maybe just use one switch to switch both at the same time?

Subject: Re: Does anyone know how to get a channel selector switch, to switch between two seperate amp's chan

Posted by [real_one](#) on Mon, 10 Dec 2007 17:22:43 GMT

[View Forum Message](#) <> [Reply to Message](#)

Use a multi pole switch (like DPDT, 3PDT, etc) to trigger both distortion foot switch inputs at the same time.