

---

Subject: PiAlign Question...

Posted by [jsalve](#) on Sat, 20 Oct 2001 23:21:28 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi Wayne,I've been trying different drivers in your PiAlign software and have a question about Lo Cutoff with regards to port dimensions. When I enter different values for Lo Cut the port size does not change. Am I doing something wrong? Or is this normal?I am building a PI Cornerhorn for my brother. He's been hounding me for the last few months to build him one. I promised him after the job hunt is over. Well I was finally offered a decent job, so no more excuses.Thanks,Jeff

---

Subject: Re: PiAlign Question...

Posted by [Wayne Parham](#) on Sun, 21 Oct 2001 00:40:44 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi Cut and Low Cut don't do anything in PiAlign. They're informational only. When I originally wrote this program, I was going to have it calculate a crossover too. But that would have required more data than could be entered in this format, so I didn't have it do any calculations, leaving the fields as info only fields.

---

Subject: Re: PiAlign Question...

Posted by [jsalve](#) on Sun, 21 Oct 2001 03:06:29 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Thanks for your help.Jeff

---