
Subject: 1600 HZ crossover (4 Pi)
Posted by [Zeno](#) on Fri, 12 Apr 2002 10:08:08 GMT
[View Forum Message](#) <> [Reply to Message](#)

wayne,sorry for asking a stupid question, can you please tell me the crossover diagram for the 4 Pi 1600 Hz which is the positive input and which is the negative inputZV

Subject: Re: 1600 HZ crossover (4 Pi)
Posted by [Wayne Parham](#) on Fri, 12 Apr 2002 17:54:46 GMT
[View Forum Message](#) <> [Reply to Message](#)

Polarity really doesn't matter as long as you stay consistent throughout the installation. I make the connection shown as the bottom lead on the schematic negative, for the loudspeaker cabinet input, and for the woofer and the tweeter. You can call this side "ground" if you want, but it is really just one side of a pair.

Subject: Re: 1600 HZ crossover (4 Pi)
Posted by [Zeno](#) on Sat, 13 Apr 2002 00:08:08 GMT
[View Forum Message](#) <> [Reply to Message](#)

thanks wayne