
Subject: Hornresp MMD spec
Posted by [Adrian Mack](#) on Thu, 27 Mar 2003 07:54:21 GMT
[View Forum Message](#) <> [Reply to Message](#)

Hey everyone. Am using Hornresp now, and it needs something called Mmd. Is this the same as Mms? If not, how can I calculate Mmd from the other t/s specs? Thanks! Adrian

Subject: Re: Hornresp MMD spec
Posted by [Smrtislav](#) on Thu, 27 Mar 2003 17:23:22 GMT
[View Forum Message](#) <> [Reply to Message](#)

Hi, in almost every window in the driver parameters section pressing pops up a window, where you put T/S parameters in and the program computes the value. Or it is in the menu under Tools-Convert parameter.K.

Subject: Re: Hornresp MMD spec
Posted by [Wayne Parham](#) on Thu, 27 Mar 2003 17:33:04 GMT
[View Forum Message](#) <> [Reply to Message](#)

MMD is the moving mass of the diaphragm. There is a conversion tool that is made available when you double-click on this parameter in edit mode. Just click twice and Hornresp will ask you some questions and then calculate MMD for you using the information provided.

Subject: Thanks Guys (NT)
Posted by [Adrian Mack](#) on Thu, 27 Mar 2003 22:10:46 GMT
[View Forum Message](#) <> [Reply to Message](#)
