

---

Subject: One & Two pi coil question.

Posted by [Oscarl](#) on Tue, 10 Jun 2003 12:41:27 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

The .5mH coil has two terminals (one from the centre and one from the outside). Does it matter which side fits where in the cable assembly??? (which one to the speaker terminal and which one to the binding posts)thanx Oscar

---

Subject: One & Two pi coil answer

Posted by [Wayne Parham](#) on Tue, 10 Jun 2003 18:02:37 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

An inductor isn't polarized, so it can be connected either way. In the kits, we have the black (-) terminal of the speaker connector tied to the (-) terminals on the tweeter and the midwoofer. The red (+) terminal ties to the tweeter (+) connector, and also goes through the coil and on to the midwoofer's (+) connector.