
Subject: Wayne- L2 for Stage 4's ?
Posted by [Matts](#) on Mon, 10 Apr 2006 17:39:35 GMT
[View Forum Message](#) <> [Reply to Message](#)

I can't find the value on the schematic- says it's a different value with the 1K6xx xover, but doesn't say what it is. Building an "upgrade" xover....Thanks!

Subject: Re: Wayne- L2 for Stage 4's ?
Posted by [Wayne Parham](#) on Mon, 10 Apr 2006 19:40:24 GMT
[View Forum Message](#) <> [Reply to Message](#)

L2 = 1.0mH

Subject: Re: Wayne- L2 for Stage 4's ?
Posted by [Matts](#) on Mon, 10 Apr 2006 21:08:42 GMT
[View Forum Message](#) <> [Reply to Message](#)

thanks. Was wondering, because there's a footnote on the schematic that says it's "1.0mH except for woofers using crossover 1K6...", but it didn't say what it did use.
