
Subject: Pushed in Dust Cap

Posted by [jshoc](#) on Sun, 23 Jul 2006 23:22:18 GMT

[View Forum Message](#) <> [Reply to Message](#)

Well, the inevitable happened. My youngest son was playing around my speakers with a buddy of his, and accidently pushed in the dust cap on on 15in Eminence woofers. Any advice on how to get it back to its original symmetrical shape? I tried a vacuum nozel up against the pushed in area - didn't help much. Thanks Jim

Subject: Re: Pushed in Dust Cap

Posted by [Wayne Parham](#) on Mon, 24 Jul 2006 05:24:16 GMT

[View Forum Message](#) <> [Reply to Message](#)

There's a "good" way and a "better" way to fix a dented dust cap. You can use a needle like a hook, pressing it into the cap and using it to pry out the dent. That's a good way to do it. A better way is to buy a replacement cap, cut the old one off and glue on a new one.

Subject: Re: Pushed in Dust Cap

Posted by [Crazy Dave](#) on Mon, 24 Jul 2006 19:52:40 GMT

[View Forum Message](#) <> [Reply to Message](#)

Tape, rolled backwards on you finger can also work well. If you destroy it, at least you can get an exact replacement from Eminence. If your speakers are in a place of public access in you house, you should really cover them. I sold audio for years and I can tell you that both children and adults, can resist pushing in dust caps and tweeter domes. It's something that's hardwired into us! Dave

Subject: Re: Pushed in Dust Cap

Posted by [jshoc](#) on Mon, 24 Jul 2006 22:28:34 GMT

[View Forum Message](#) <> [Reply to Message](#)

Thanks for the advice. I am tempted to try a vacuum hose on the dust cap. Concern would be that it dislocate the voicecoil...

Subject: Re: Pushed in Dust Cap
Posted by [Shane](#) on Tue, 25 Jul 2006 01:56:12 GMT
[View Forum Message](#) <> [Reply to Message](#)

I've had good luck using the tape method. Just make sure you take a little of the sticky off if the tape is real tacky.
