Subject: Re: correct dc voltage for the Thorens 147 turntable
Posted by pinloong on Tue, 19 Apr 2005 05:42:01 GMT
View Forum Message <> Reply to Message

Thank you, manualblock. Just saw the piece of paper pasted on the tt chassis when the platter was removed. It says something like 15v or more but it also has a wave sign(ac?). Just wondering what that means but I am getting a 16volter as you indicated. Or one as close as possible if I can't?