Subject: Re: correct dc voltage for the Thorens 147 turntable
Posted by Manualblock on Wed, 20 Apr 2005 00:13:44 GMT
View Forum Message <> Reply to Message

The unit is a 16v AC adapter. Be sure to get AC transformer; it looks like a wall-wart.