Subject: Re: Digitizing Audio
Posted by Wayne Parham on Sat, 12 Apr 2008 20:35:19 GMT
View Forum Message <> Reply to Message

Best thing is to set the output level as high as possible that won't overdrive the input. Check peak levels for clipping and then back down just a tiny bit to make sure.The reason you want the output drive as high as possible is this makes the signal to noise ratio as high as possible.