Subject: Re: Pro Sound Driver Sensitivity
Posted by Bill Fitzmaurice on Mon, 28 Feb 2005 22:38:16 GMT
View Forum Message <> Reply to Message

True, and the resulting high fs and low Qts quite often will result in cent 3: No bass. Unless you put them in horns or other boxes that can bring the bass response up, that is. Newbies very often toss pro-sound drivers into inadequate boxes and are puzzled why they have no bass response. The steps required to gain high sensitivity is why.