Subject: Power tapering Idea - Mass loading ?
Posted by flacoman on Fri, 14 Jan 2005 16:29:29 GMT
View Forum Message <> Reply to Message

That's the exact idea . If I spread the power handling out across enough drivers , I should likely br OK. I'm thinking along the lines of a few coats of epoxy spray paint to stiffen the cone and a topcoat of damping goop. Having loaded up largish woofers in the past , I can't say too much about the midrange qualities of such a driver Thanks all ,and more comment welcomed .peaceJorge