Subject: Almost forgot...
Posted by Damir on Sat, 04 Jun 2005 04:26:55 GMT
View Forum Message <> Reply to Message

If you`ll use 800V transformer, you`ll need (at least) 1200V diodes and first cap (Utr*1,4142).Lot of simulations are in order first, I think