Subject: Wall Drug
Posted by PakProtector on Sun, 05 Jun 2005 10:34:56 GMT
View Forum Message <> Reply to Message

with silicon PN junction diodes, putting them in series gives you a PIV which is the sum of the individual PIV's. SiC is not the same,regards,Dogulashope you got some sleep