Subject: Hot T-nuts, HotTnuts - Dizzy Gillespie
Posted by BillEpstein on Sat, 17 Aug 2002 15:37:25 GMT
View Forum Message <> Reply to Message

What you want to do is push the nut into the hole as far as you can with finger pressure, (which isn't very far) then run your screw from the outside as though you were installing the drivers but with a big fender washer to keep the screw from ruining the hole. Make sure all 3 tangs of the nut are biting the wood and tighten down until the tangs are fully into the wood.It's time-consuming but the only way to keep those thangs seated. I see posts that recommend a dab of glue in the hole but I don't like to have to worry about gluing the screw, or screwing the glue.