Subject: Pro Series 7 Pi-18 answers
Posted by Wayne Parham on Fri, 04 Oct 2002 04:54:16 GMT
View Forum Message <> Reply to Message

You'll need 1/4"-20 bolts to mount the horn on the driver. As for mounting to the cabinet, I suggest machine screws and T-nuts:Post some pics when you can, those sound gorgeous!