Subject: Re: sounds OK
Posted by Wayne Parham on Tue, 17 Dec 2002 19:04:02 GMT
View Forum Message <> Reply to Message

I'd line the front panel interior with insulation, and put the woofer and port both on the back panel. In this manner, the front baffle won't act as a reflector, bouncing midrange enrgies into the port. I'm assuming you're building cornerhorns, as I recall, that's what you're building. If they were bass-reflex boxes, I'd line the rear panel with insulation, and put the woofer and port on the front panel, so it's essentially the same thing but reversed.