Subject: silly seven cornerhorn question
Posted by artsybrute on Wed, 21 Jan 2004 15:42:19 GMT
View Forum Message <> Reply to Message

Hi again.I've got all the wood cut up (except for the doghouse angles) and am running out to Home Depot for the insulation.I understand it should be 2" stuff without backing, which I think is R-13.How does the insulation get attached? The only reference I can find is in the attached link which specifies PL400 Deck Adhesive. What is that, and if I cannot find it what is the generic name for something I could use?Thanks,Len
One for the Fridge post