Subject: Re: Mounting Eminence Driver
Posted by Wayne Parham on Sun, 24 Feb 2008 23:07:52 GMT
View Forum Message <> Reply to Message

When I use T-Nuts, I usually use 10-32 size with button head or hex head screws.  But for the

these fasteners:Black pan screws for mounting small driversT-Nuts are good when post-construction serviceability is a concern, like for prosound speakers.  But if you won't be going inside your speakers a lot, these screws are fine.  They look good and will hold until about 20 loosening/tightening cycles, when the wood will stretch enough to tear through.