Subject: Re: R11/13??
Posted by Wayne Parham on Tue, 22 Apr 2008 23:58:58 GMT
View Forum Message <> Reply to Message

On the midrange cabinet, just loosely fill the rear chamber. On the bass bin, put it on one side, top and face. Also put two pieces spanning the cross-section along the braces, sort of dividing the cabinet into thirds.