Subject: Re: Where To Learn More?
Posted by Wayne Parham on Mon, 31 Jan 2011 00:00:31 GMT
View Forum Message <> Reply to Message

At low frequencies, you have to make the absorbers physically large for them to do any good. Framed drywall construction actually provides a fair amount of damping because the walls have some "give". Panel absorbers - sort of like large false walls - can be used in rigid rooms that have brick, stucco or concrete.
"False wall" bass trap panels