Subject: Attaching drivers.
Posted by justphil on Thu, 19 May 2011 23:52:01 GMT
View Forum Message <> Reply to Message

are "T" nuts suggested or are wood screws fine?

Also I know you were using that shower stuff for gasket material. At my work we something called butyl tape. Its a gummy substance they used to use to seal and set windshields in cars. Is something like this a good thing to use?
Thanks,
Phil