Subject: Re: Driver Removal
Posted by Wayne Parham on Tue, 25 Oct 2011 14:44:53 GMT
View Forum Message <> Reply to Message

I use an Allen wrench to lift the woofer (or horn) from the mounting holes. Remove all the screws, and put a decent size Allen wrench in the hole. Tilt until it catches and lift out, basically using the wrench as a prybar.