Subject: jvc produces no sound
Posted by jvc on Sat, 21 Jan 2006 15:04:32 GMT
View Forum Message <> Reply to Message

My new-to-me JVC AL-F350 turns and tracks fine but produces no sound through the output jacks. Any suggestions? Thanks

Subject: Re: jvc produces no sound
Posted by Wayne Parham on Sat, 21 Jan 2006 20:08:57 GMT
View Forum Message <> Reply to Message

What's it hooked to?

Subject: Re: jvc produces no sound
Posted by jvc on Sun, 22 Jan 2006 03:52:45 GMT
View Forum Message <> Reply to Message

I have it hooked to about a three year old Sony reciever. After playing with it for most of the day I can get some sound but its very soft. I've hooked up a tape deck using the same in jacks and the sound is normal. Not sure if there is something in the record player that controls output volume. Thanks.

Subject: Re: jvc produces no sound
Posted by Wayne Parham on Mon, 23 Jan 2006 03:24:36 GMT
View Forum Message <> Reply to Message

You probably need a phono preamp. If your cartridge is magnetic and you don't have a magnetic phono input, you'll need a phono stage.

Subject: Re: jvc produces no sound
Posted by john doe on Wed, 01 Feb 2006 07:39:27 GMT
View Forum Message <> Reply to Message

phono is the RIAA curve boosting the highs and cutting the lows .on play back the reverse applies to bring down the hiss .its been like that forever so you WILL need a phono stage in your signal chain

---

Subject: Re: jvc produces no sound
Posted by Wayne Parham on Wed, 01 Feb 2006 14:51:34 GMT
View Forum Message <> Reply to Message

Very true. If a turntable is plugged into an un-equalized (non-phono) input, the sound will be very tinny because of the RIAA curve. But if a magnetic cartridge is plugged into a ceramic input, the RIAA curve will already be applied. It will just need more gain.
