Subject: Compressed fiber carpet pad for cabinet damping?
Posted by Garland on Sun, 16 Dec 2001 00:04:02 GMT
View Forum Message <> Reply to Message

I have a bunch of this wool-like 1/2" thick carpet pad that I got for use in a tapered quarter wave tube project and was wondering if it can adeqately be used to line the specified interior sufaces of my Theater 4's? It is pretty dense stuff- not fluffy like insulation that I've heard is OK to use. Can anybody help me out here? What is best to use? Thanks!Garland

Subject: Use 2" fiber-filler
Posted by Wayne Parham on Sun, 16 Dec 2001 01:21:10 GMT
View Forum Message <> Reply to Message

I'm afraid that stuff will be too thin and dense. Use 2-3" thick fiberfill like is in the attic of your home. R11 or R13 is perfect.