Subject: ZMAX How ?
Posted by Ciscokid on Thu, 15 Aug 2002 23:09:10 GMT
View Forum Message <> Reply to Message

Hi, Sorry for such a basic question. However, I did a search on this subject and seemed to not be able to narrow down to specific answer. So here is my question. How do you derive the ZMAX of a speaker? Best regards,ck

Subject: ZMAX - Maximum impedance, impedance at resonance
Posted by Wayne Parham on Fri, 16 Aug 2002 01:30:01 GMT
View Forum Message <> Reply to Message

The maximum impedance of a speaker is found at resonance. You can measure it with a test resistor, an oscilloscope or meter and a signal generator. The test resistor is placed in series with the speaker, and you will measure the voltage divided between the speaker and the resistor at its maximum point. Use a resistor value equal to the expected Zmax, between 50 and 200 ohms. The value should be precisely known because you will use it as a reference point; The division of voltage between the resistor and the speaker at resonance is used to calculate Zmax.The resonant frequency is where the voltage across the speaker is highest, and across the resistance is lowest. At this point, perform two simple measurements:1. Measure the voltage across the known-value reference resistor. Calculate current using Ohm's Law:I = E / R2. Measure the voltage across the speaker. At resonance, speaker impedance is purely resistive so the voltage across the speaker should be equal to the source voltage minus the drop from the resistor. Double check that this is true, and also calculate Zmax using the voltage across the speaker and the calculated current:Zmax = E / ISpeaker impedance is purely resistive at only at resonance, so these simple formulas will only work at this particular frequency. Reactive circuit formulas using vectors must be used to calculate impedance at other frequencies. But for Zmax, this simple measurement is perfectly adequate.

Subject: Re: ZMAX - Maximum impedance, impedance at resonance
Posted by Ciscokid on Fri, 16 Aug 2002 17:53:32 GMT
View Forum Message <> Reply to Message

Thanks Wayne, I was hoping that it would be a matter of taking the THIELE/SMALL parameters and deriving the ZMAX. I notice a lot of speaker manufactures provide those numbers, however; they don't seem to provide the ZMAX. Is there a way to tell from the THIELE/SMALL parameters weather a particular speaker would be good for a low powered tube amp? Best regards,ck

Subject: Re: ZMAX - Maximum impedance, impedance at resonance
Posted by Wayne Parham on Fri, 16 Aug 2002 18:37:31 GMT
View Forum Message <> Reply to Message

There was an earlier discussion about something like this. Check the thread called "piAlign software and figuring Zmax".