

---

Subject: Re: tried the 6688

Posted by [Damir](#) on Mon, 19 Jun 2006 05:02:17 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Forgot to add - check for oscillations, I have a problem with all those high-gm tubes. Use g1 stopper, g2 stopper (g2 to anode), and use both cathode connections - I use two resistors, but one Rk+wire bypass to other cathode pin worked, too. Where you connected g3? Somehow I can't believe that you and I get totally opposite results?!

---