Subject: Re: Ping Steve Brown -- re: Seth(s)
Posted by Skip Pack on Mon, 17 Dec 2007 13:46:13 GMT
View Forum Message <> Reply to Message

Steve,Thanks for the reply. Too many sites these days, it's easy to miss something, somewhere. In any case, I was wanting to isolate the driverstage from the output stage, and since I have 2 220 VAC secondaries onthe power transformers, I was originally thinking to put one bridgeacross one of the secondaries, and then another across both in series.I have since seen a discussion on AA that suggests that this would becatastrophic (though I don't quite see how). If I had the 400+ B+ forthe driver, I would drop it with a large, hot resistor and maybe a choke to further isolate that stage. I suspect that simply using onesecondary with a CLCLC for the output at full voltage and a chokeloaded LCLC(maybe one more LC) for the driver would work as well orbetter and avoid the higher voltage complications.Skip