

---

Subject: Re: Energy along frequency spectrum

Posted by [Wayne Parham](#) on Thu, 27 May 2004 22:52:31 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Most energy is required in the midrange, followed by midbass and bass. There's less power requirement for the HF amp in a bi-amped system because there's generally less signal content. Also, because the HF signal isn't riding on top of a LF signal, removing the LF component makes less of a peak-to-peak voltage requirement too. Rod Elliot has written a pretty good article that describes some of the issues. Check it out:

Benefits of Bi-Amping

---