
Subject: Consider both power and excursion.

Posted by [Bill Fitzmaurice](#) on Fri, 16 Apr 2004 11:30:21 GMT

[View Forum Message](#) <> [Reply to Message](#)

What limits a tweeters ability to run with a 1st order crossover is both power and excursion. The power reduction afforded by a capacitor at 6dB per octave is generally adequate to counter the rising program power input, on average 3dB per octave, as one goes lower in frequency, giving a net reduction of 3dB per octave, assuming a reasonably robust voice-coil. However, since excursion increases by a factor of 4(6dB) per octave as frequency drops for equal power input then even with a net power input reduction of 3dB/octave the excursion demand will rise at 3dB/octave. That being the case I wouldn't consider a 1st order filter unless the corner frequency was set to at least 4 times F_s . On the other hand, you can go to the other extreme as well with a very high order crossover. Neville Thiele has recently shown that with a 5th order high-pass you can run the corner frequency very close to the F_s without any difficulty from either the power or excursion standpoint, and the additional octave or two of operating range thus afforded can well offer the opportunity to run two-way rather than 3-way. This works very well with a 3rd order low-pass on the woofer as far as integration goes, and offers a parts cost reduction as well compared to a 4th order/4th order arrangement due to the lessened high value inductor count.
