
Subject: Re: starting construction on bass horn ?

Posted by [Bill Fitzmaurice](#) on Sat, 26 Jun 2004 19:14:24 GMT

[View Forum Message](#) <> [Reply to Message](#)

The front chamber would be the volume of the air space between the cone and the baffle if there is no other separate compartment. The front chamber size in combination with the throat size affects LP filtering and F_s alteration. X_{max} is a one way measurement but it is only considering the voice coil overhang, not potential excursion. Some manufacturers list the destructive X_{max} , which is when the coil hits the backplate, and that's the depth you'd use for the spacer, inclusive of the driver gasket. If you can't find the destructive X_{Max} then go with twice the regular X_{Max} to be safe.
