Subject: Measuring sensitivity
Posted by JLapaire on Thu, 03 Mar 2005 18:37:12 GMT
View Forum Message <> Reply to Message

I can measure sensitivity at a certain frequency by setting drive voltage at, say, 2.83v and reading the SPL meter at 1 meter distance, but can't seem to get the DVM to settle with pink noise.I use TruRTA for tuning, but mistrust the sensitivity readings because there seems to be a big difference in drive between sine and pink, and I can't check it with the DVM. Am I missing the boat somewhere?Thanks,John