
Subject: Re: Is calculations of L-pads based on "nominal impedance" or Re?

Posted by [Peter K](#) on Wed, 29 Mar 2006 16:05:01 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hi Wayne, Thanks a lot for your reply! Smoothing out the impedance curve is actually the main reason why I want to use L-pads (I will use an active crossover between the bass and the BMS, so level matching is not really necessary, but I may have to level between the BMS mid and high section [the BMS is a "coax"]). Below I have attached a link to the BMS driver. In the second graph of the driver's response the impedance curve is shown (I know the horn is different than the one I will be using, so the response will not be completely identical on my horn). Unfortunately, I haven't got measuring equipment myself, so I can not provide an impedance plot of the driver on my horn. But given the info provided (nominal impedance: 16 Ohm, $R_e = 8.9$ Ohm, and the graph in the link), may I ask: Which R-value would you base the L-pad calculation on? I would really appreciate your expert opinion on this - thanks! Regards Peter

BMS 4592 ND driver
