
Subject: Re: How do I measure the L_e of a speaker?

Posted by [Wayne Parham](#) on Wed, 05 Apr 2006 15:28:21 GMT

[View Forum Message](#) <> [Reply to Message](#)

Measure the impedance of the speaker to find L_e . It will be a complex impedance, having both reactance and resistance. You can use a Wheatstone bridge (inside a dedicated tester) or one of the measurement systems like Speaker Workshop to find impedance of your speaker.
