
Subject: Re: Heavy-cones verses light-cones in basshorns

Posted by [GM](#) on Sun, 27 Aug 2006 19:09:03 GMT

[View Forum Message](#) <> [Reply to Message](#)

>Heavy cones have lower resonance.....Greetings!Not necessarily: $F_s =$

$[(1/\pi)/2]^* \{ [1000/(M_{ms} * C_{ms})]^{0.5} \}$ where: M_{ms} is in grams and C_{ms} is in m/N=====>To say light cones are better or heavy cones are better is like saying stiffer springs are better for a car. It depends on what size car they go in, and what type of ride is desired. That's my opinion.=====>Yep, it all depends on the desired BW and acoustic power/watt you want. If I only need it to load 30-100 Hz, why force a 40 Hz F_s driver with a 400 Hz HF mass corner to do it?GM
