

---

Subject: Power Tapered to 12 drivers of 4ohms  
Posted by Renato on Tue, 17 May 2005 17:38:05 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Dears Friends,I need impedance result more ou less, in 6 ohms, I think use below  
arrange:#1#2#3#4#5#6Tweeter#7#8#9#10#11#12Option

A===== (6,7)+(3,4,5)+(8,9,10)+(1,2,11,12) = 5,66 ohmsOption

B===== (1,2,3,4)+(5,6)+(7,8)+(9,10,11,12) = 6 ohmsOption

C===== ((1,2,3)+(4,5)+(6,7)+(8,9)+(10,11,12) = 8,66 ohmsOther option ? Any problem to this configurations for 12 divres of4ohms and what te best, and why ?Ps. My English is to bad for write, but I read without problem.Tks,Renato

---