

---

Subject: Re: Damn Holes

Posted by [Anonymous](#) on Fri, 24 Jun 2005 20:12:54 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I know what you mean, I had to do some tests and shim my router bearing with masking tape to get the precision cut to make the NSBfit perfect. Since the damage is done and you have bigger holes your choices to repair are limited. If the front baffle is to be painted or veneered later you can fix the problem with automotive bondo. Apply masking tape to the front baffle side of the hole and add bondo to the hole to shrink diameter, a small layer with your finger. Let cure then sand off as much as you need. The cheap solution is weather stripping on the NSB frame but it may look ugly. Trim rings may work but that is a lot of work. Rear mounting the NSB is another option. Pick a poison. /hehe

---