

---

Subject: ribbon protection with electronic crossover?

Posted by [Steven Homrighausen](#) on Tue, 03 Apr 2007 00:38:37 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

If building an array using an electronic crossover and ribbon tweeters - a capacitor is needed between the amp and the tweeter line. How do I figure the value of that capacitor? Is there a general rule for the value? I don't want it to affect the crossover frequency set via the electronic crossover. I was thinking about two octaves below the crossover point - am I making this too simple? The steeper the crossover slope, the closer this cap can be?

---