Subject: Troubleshooting
Posted by Manualblock on Tue, 08 Mar 2005 22:52:49 GMT
View Forum Message <> Reply to Message

Well; here we go. Seems I am blowing fuses upon switching my unit on. I have gone over the trans and PS wireing and it all checks out and looks good. Can a shorted lead on the CCS cause a fuse out on power up?The tranny is Blue/Red secondaries to the anodes of the 6CA4(250V)Red/Yellow to chassis groundYellow 5v secondaries to the Filament heater pins of the rec tubeCathode to the choke Choke to PS cap +The two primary black wires/ one to the AC input and the other to the switchThen from the switch to the fuse to the AC input neutral return