
Subject: Behaviour of vented loudspeaker systems

Posted by [Wayne Parham](#) on Mon, 17 Jun 2002 02:25:48 GMT

[View Forum Message](#) <> [Reply to Message](#)

All bass-reflex systems have two impedance peaks, f_l and f_h . The Helmholtz frequency (f_b) and the free-air resonance of the woofer (f_s) interact and modify each other to create f_l and f_h . Minimum excursion is at f_b and maximum is below f_l , where excursion tends to rise rapidly as frequency goes down. The woofer is unloaded under f_l and the woofer is for all practical purposes moving as it would in free air. There is another maximum at f_h and this is the one you should concern yourself with the most. Excursion at f_h should not exceed X_{max} . You can high-pass the woofer to remove signals from being presented to it below f_l in a high-power application because it will not be generating any useable output below f_l anyway. But f_h is in the passband, so this sets your excursion limit.

At frequencies below f_l , the woofer and port are moving together, so that the woofer goes out when the port's air mass goes in. This causes complete cancellation, and the system is unloaded. But as frequency rises above f_l - as frequency passes through f_b - the two resonators are moving towards a condition where they push against one another and provide an in-phase signal. That's why diaphragm excursion is reduced at f_b , the air mass in the port is moving opposite to the diaphragm. Between f_b and f_l , the system is still resonant but not as tightly coupled. Above f_h , the system is no longer at resonance and the port is for all practical purposes acoustically invisible. At frequencies above f_h , it is like it weren't even there at all.

As we rise much beyond f_h , the port begins to act as though it weren't there. Pressure changes are too rapid for the area of the port to be of any significance, so above f_h , the port does nothing at all. Of course, there is a possibility of wavelength-related phenomenon, but that is why we use acoustic insulation in the cabinet. We want to minimize wavelength related phenomenon and ensure that the significant mechanism be only that of the Helmholtz resonator and its interaction with the woofer. In this way, the f_l - f_b - f_h resonance region mentioned above is all that is affected by the system.