
Subject: starting on pseudo vots/4 pi's (sorry for the double post)

Posted by [EZ_Angus](#) on Fri, 09 Aug 2002 13:08:37 GMT

[View Forum Message](#) <> [Reply to Message](#)

I scored a pair of 416-8a's from EBAY and am starting to plan their boxes out whilst I continue to hunt for 802's and 511b's (jammin jersey is just to expensive for me). Wayne was good enough to run the specs for the 416-8b's and since i can't find specs for the a, I am going to go with them. they were:"PiAlignments for that motor specify a cabinet of 8.5 cubic feet tuned to 30Hz. It further recommends a rectangular port having inside dimensions of 6" x 10.5" and 14" long. The response is nice and flat, with a -3dB point of 40Hz and -10dB at 23Hz. This is a very nice speaker with very full bass" So I am thinking of the cabs being 18" wide x 18" deep by 45.5" tall. that makes 8.5 CF right :^). I like the look of the horn being wider than the cab, like those "210 split" cabs in sound practices. I figured with a 15" woofer I shouldn't make it much narrower than 18" though. The port I was going to have 14" wide, 6" tall and 10.5" deep. Is that cool? I love deflex pads so will use them for damping. I don't like to heavily damp cabs. If I use 3/4" plywood, do I need bracing? anybody have any comment/suggestions? I am thinking of making them from cherry and maple veneered plywoods (sides cherry, top and at least part of the front maple for a cool contrast).by the way Wayne if you see this, I bought a Paramour kit also in the last hour of their sale. I think it will take a couple months to arrive.EZ, aka Kevin