
Subject: Re: Resistor attenuation

Posted by [Wayne Parham](#) on Sun, 11 Aug 2002 21:12:01 GMT

[View Forum Message](#) <> [Reply to Message](#)

Generally, speakers like this sound a little bass-shy in large rooms or outdoors. That's why subwoofers are often used. Indoors, they usually sound pretty balanced, although subwoofers are sometimes still employed to smooth room modes. My guess is that your room is pretty lively, either hardwood paneling or glass and not a lot of furniture. In that case, I would suggest just turning the treble down a notch, but you can also do that by modifying the crossover to attenuate the tweeter a little more. The schematic included in the plans show a chart of values for various levels of attenuation. The 10dB unit has $R1=16$, $R2=16$ and $C1=0.47$, the 12dB unit has $R1=25$, $R2=16$ and $C1=0.47$ and the 14dB unit has $R1=30$, $R2=14$ and $C1=0.33\mu F$. You could install the 12dB or 14dB values.