
Subject: Formulas

Posted by [Wayne Parham](#) on Sat, 24 May 2003 11:33:24 GMT

[View Forum Message](#) <> [Reply to Message](#)

You will need to use the formulas for calculating impedance and power through a reactive circuit, which isn't quite the same as pure resistance. The formulas are in the "Pi Alignment Theory" document and in electronics textbooks. Impedance is found using reactive impedance

reactance, in ohms X_C is capacitive reactance, in ohms F is frequency, in Hertz L is inductance in Henries (so mH is $H \times 10^{-3}$) C is capacitance in Farads (so μF is $F \times 10^{-6}$) This will tell you the impedance of your coils and caps. If you know the voltage across a component and its impedance, you can calculate the power dissipated by the device using the formula $P = E^2/Z$. If you know the current flowing through a device, you can find power by using $P = I^2Z$. So find the reactive impedance of the device in question at the desired frequency, and substitute that for "Z."
