
Subject: System and motor damping and some other stuff....

Posted by [Adrian Mack](#) on Sat, 28 Jun 2003 02:11:04 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hi everyone, I have some idea on this topic, but I've yet to find any real facts on what system and motor damping is, and also how the amplifiers damping factor relates to this. Maximum impedance affects motor damping and high amplifier damping factors are required for high Z_{max} woofers, but I'm not too certain on what system and motor damping actually is/how it works. Also, exactly why are high Q ts motors a "bad" thing? (using the term loosely). That is, besides having poor cone control (because of high Q ms?) and being a pain in the ass to get frequency linear with low THD. Is there any way you could use well a high Q motor (I think some of the Pi speakers have high Q ts motors like the Alpha 15 in some of the bass reflex designs) in a vented box? or even sealed. I wonder why some drivers have extremely high Q ts, which aren't too usable in much else besides IBs in most cases. Is there any reason not to stuff a ported box? Most people simply say that if you stuff it, it will be like a sealed box. Others just say line each wall, which is what I usually say myself too. But none have yet to offer a good reason why it can't be stuffed. Of course the apparent box volume will increase due to stuffing, and we can't really know how much this would be by, making design hard. If we did know how much increase in box volume the stuffing would contribute exactly, is there any reason not to design a ported system around this basis? What parameters affect driver voice coil inductance, L_e ? Is there a way to calculate L_e (at 1Khz standard)? Is there a way to increase driver efficiency without sacrificing anything else? I've heard that increasing motor strength by means of flux density can achieve this, but I'm not sure. If a more-than-needed motor strength is used on a motor, why is bass response poor/driver resonance increased? Larger V_{as} = higher efficiency, however V_{as} doesn't really have anything to do with efficiency, it's the motor strength and moving mass that govern efficiency, correct? This is what Dan Wiggins said on another forum, giving the reason that C_{ms} cancels out in the efficiency equation. Not 100% sure on his reasoning, even though it seems correct. What does "shelving" mean? Building my tractrix horns in 1.5 weeks :-). Hope they sound good lol. I think they should, I'll post pictures for anyone that's interested or that can remember me building horns. Hope somebody can answer at least some of my questions :-). TIA! Adrian