
Subject: Re: Modeling effects of XOver

Posted by [Wayne Parham](#) on Tue, 02 Dec 2003 20:37:35 GMT

[View Forum Message](#) <> [Reply to Message](#)

Those are the correct formulas for calculating reactive impedance, but the impedance figures given should not be considered the same as resistance. Resistance is a dissipative load whereas reactance is a reflective load. Pure reactance doesn't actually absorb power and do work; Instead, it reflects the energy back. This property is described by considering reactive impedance to be out of phase with resistance by 90°; It is expressed as an imaginary term with the value i or the square root of -1 . As such, reactances must be combined as vectors. You might want to get an electronics textbook and study AC circuits and reactive impedance. That will shed some light on this for you.